

PRELIMINARY

May 1988

NS32C201-10/NS32C201-15 Timing Control Units

NS32C201-10/NS32C201-15 Timing Control Units

General Description

The NS32C201 Timing Control Unit (TCU) is a 24-pin device fabricated using National's microCMOS technology. It provides a two-phase clock, system control logic and cycle extension logic for the Series 32000® microprocessor family. The TCU input clock can be provided by either a crystal or an external clock signal whose frequency is twice the system clock frequency.

In addition to the two-phase clock for the CPU and MMU (PHI1 and PHI2), it also provides two system clocks for general use within the system (FCLK and CTTL). FCLK is a fast clock whose frequency is the same as the input clock, while CTTL is a replica of PHI1 clock.

The system control logic and cycle extension logic make the TCU very attractive by providing extremely accurate bus control signals, and allowing extensive control over the bus cycle timing.

Features

- Oscillator at twice the CPU clock frequency
- 2 phase full V_{CC} swing clock drivers (PHI1 and PHI2)

- 4-bit input (WAITn) allowing precise specification of 0 to 15 wait states
- Cycle Hold for system arbitration and/or memory refresh
- System timing (FCLK, CTTL) and control (RD, WR, and DBE) outputs
- General purpose Timing State Output (TSO) that identifies internal states
- Peripheral cycle to accommodate slower MOS peripherals
- Provides "ready" (RDY) output for the Series 32000 CPUs
- Synchronous system reset generation from Schmitt trigger input
- Phase synchronization to a reference signal
- High-speed CMOS technology
- TTL compatible inputs
- Single 5V power supply
- 24-pin dual-in-line package



©1995 National Semiconductor Corporation TL/EE/8524

RRD-B30M105/Printed in U. S. A.

Tak	ble of Contents
1.0 FUNCTIONAL DESCRIPTION	2.0 DEVICE SPECIFICATIONS
1.1 Power and Grounding	2.1 Pin Descriptions
1.2 Crystal Oscillator Characteristics	2.1.1 Supplies
1.3 Clocks	2.1.2 Input Signals
1.4 Resetting	2 1 3 Output Signals
1.5 Synchronizing Two or More TCUs	2.2 Absolute Maximum Ratings
1.6 Bus Cycles	2.3 Electrical Characteristics
1.7 Bus Cycle Extension	2.4 Switching Characteristics
1.7.1 Normal Wait States	
1.7.2 Peripheral Cycle	2.4.1 Delimitions
1.7.3 Cycle Hold	2.4.2 Duiput Loading
1.8 Bus Cycle Extension Combinations	2.4.4 Timing Diagrams
1.9 Overriding WAIT Wait States	2.4.4 Timing Diagrams
List	of Illustrations
Crystal Connection	1-1
PHI1 and PHI2 Clock Signals	
Recommended Reset Connections (Non Memory-Man	aged System)1-3a
Recommended Reset Connections (Memory-Managed	l System)1-3b
Slave TCU does not use RWEN during Normal Operati	on1-4a
Slave TCU Uses Both SYNC and RWEN	1-4b
Synchronizing Two TCUs	
Synchronizing One TCU to an External Pulse	
Basic TCU Cycle (Fast Cycle)	
Wait State Insertion Using CWAIT (Fast Cycle)	
Wait State Insertion Using WAITn (Fast Cycle)	
Peripheral Cycle	1-10
Cycle Hold Timing Diagram	1-11
Fast Cycle with 12 Wait States	
Peripheral Cycle with Six Wait States	1-13
Cycle Hold with Three Wait States	1-14
Cycle Hold of a Peripheral Cycle	1-15
Overriding WAITn Wait States	
Connection Diagram	2-1
Clock Signals (a)	
Clock Signals (b)	
Control Inputs	
Control Outputs (Fast Cycle)	
Control Outputs (Peripheral Cycle)	
Control Outputs (TRI-STATE Timing)	
Cycle Hold	
Wait States (Fast Cycle)	

 Wait States (Peripheral Cycle)
 2-10

 Synchronization Timing
 2-11

1.0 Functional Description

1.1 POWER AND GROUNDING

The NS32C201 requires a single +5V power supply, applied to pin 24 (V_{CC}). See Electrical Characteristics. The Logic Ground on pin 12 (GND), is the common pin for the TCU.

A 0.1 $\mu\text{F},$ ceramic decoupling capacitor must be connected across V_{CC} and GND, as close to the TCU as possible.

1.2 CRYSTAL OSCILLATOR CHARACTERISTICS

The NS32C201 has an internal oscillator that requires connections of the crystal and bias components to XIN and XOUT as shown in *Figure 1-1*. It is important that the crystal and the RC components be mounted in close proximity to the XIN, XOUT and V_{CC} pins to keep printed circuit trace lengths to an absolute minimum.

Typical Crystal Specifications:

At-Cut
0.005% at 25°C
0.01% from 0° to 70°C
Fundamental (parallel)
50Ω



FIGURE 1-1. Crystal Connection Diagram

1.3 CLOCKS

The NS32C201 TCU has four clock output pins. The PHI1 and PHI2 clocks are required by the Series 32000 CPUs. These clocks are non-overlapping as shown in *Figure 1-2*.



FIGURE 1.2. PHI1 and PHI2 Clock Signals

Each rising edge of PHI1 defines a transition in the timing state of the CPU.

As the TCU generates the various clock signals with very short transition timings, it is recommended that the conductors carrying PHI1 and PHI2 be kept as short as possible. It is also recommended that only the Series 32000 CPU and, if used, the MMU (Memory Management Unit) be connected to the PHI1 and PHI2 clocks.

CTTL is a clock signal which runs at the same frequency as PHI1 and is closely balanced with it.

FCLK is a clock, running at the frequency of XIN input. This clock has a frequency that is twice the CTTL clock frequency. The exact phase relationship between PHI1, PHI2, CTTL and FLCK can be found in Section 2.



1.0 Functional Description (Continued) 1.4 RESETTING

The NS32C201 TCU provides circuitry to meet the reset requirements of the Series 32000 CPUs. If the Reset Input line, RSTI is pulled low, the TCU asserts RSTO which resets the Series 32000 CPU. This Reset Output may also be used as a system reset signal. *Figure 1-3a* illustrates the reset connections for a non Memory-Managed system. *Figure 1-3b* illustrates the reset connections for a Memory-Managed system.

1.5 SYNCHRONIZING TWO OR MORE TCUs

During reset, (when $\overline{\text{RSTO}}$ is low), one or more TCUs can be synchronized with a reference (Master) TCU. The

RWEN/SYNC input to the slave TCU(s) is used for synchronization. The Slave TCU samples the RWEN/SYNC input on the rising edge of XIN. When RSTO is low and CTTL is high (see *Figure 1-5*), if RWEN/SYNC is sampled high, the phase of CTTL of the Slave TCU is shifted by one XIN clock cycle.

Two possible circuits for TCU synchronization are illustrated in *Figures 1-4a* and *1-4b*. It should be noted that when RWEN/SYNC is high, the $\overline{\text{RD}}$ and $\overline{\text{WR}}$ signals will be TRI-STATE on the slave TCU.

Note: RWEN/SYNC should not be kept constantly high during reset, otherwise the clock will be stopped and the device will not exit reset when RSTI is deasserted.





FIGURE 1-6. Synchronizing One TCU to An External Pulse

IL/EE/0324-1

In addition to synchronizing two or more TCUs, the $\overline{\rm RWEN}/{\rm SYNC}$ input can be used to "fix" the phase of one TCU to an external pulse. The pulse to be used must be high for only one rising edge of XIN. Independent of CTTL's state at the XIN rising edge, the CTTL state following the XIN rising edge will be high. *Figure 1-6* shows the timing of this sequence.

1.6 BUS CYCLES

In addition to providing all the necessary clock signals, the NS32C201 TCU provides bus control signals to the system. The TCU senses the $\overline{\text{ADS}}$ signal from the CPU or MMU to start a bus cycle. The $\overline{\text{DDIN}}$ input signal is also sampled to determine whether a Read or Write cycle is to be gener-

ated. In addition to $\overline{\text{RD}}$ and $\overline{\text{WR}}$, other signals are provided: $\overline{\text{DBE}}$ and $\overline{\text{TSO}}$. $\overline{\text{DBE}}$ is used to enable data buffers. The leading edge of $\overline{\text{DBE}}$ is delayed a half clock period during Read cycles to avoid bus conflicts between data buffers and either the CPU or the MMU. This is shown in *Figure 1-7*.

The Timing State Output (TSO) is a general purpose signal that may be used by external logic for synchronizing to a System cycle. TSO is activated at the beginning of state T2 and returns to the high level at the beginning of state T4 of the CPU cycle. TSO can be used to gate the \overline{CWAIT} signal when continuous waits are required. Another application of TSO is the control of interface circuitry for dynamic RAMs.



1.0 Functional Description (Continued) 1.7 BUS CYCLE EXTENSION

The NS32C201 TCU uses the Wait input signals to extend normal bus cycles. A normal bus cycle consists of four PHI1 clock cycles. Whenever one or more Wait inputs to the TCU are activated, a bus cycle is extended by at least one PHI1 clock cycle. The purpose is to allow the CPU to access slow memories or peripherals. The TCU responds to the Wait signals by pulling the RDY signal low as long as Wait States are to be inserted in the Bus cycle. There are three basic cycle extension modes provided by the TCU, as described below.

1.7.1 Normal Wait States

This is a normal Wait State insertion mode. It is initiated by pulling \overline{CWAIT} or any of the \overline{WAITn} lines low in the middle of T2. *Figure 1-8* shows the timing diagram of a bus cycle when \overline{CWAIT} is sampled high at the end of T1 and low in the middle of T2.





1.0 Functional Description (Continued) 1.7.2 Peripheral Cycle

This cycle is entered when the $\overrightarrow{\text{PER}}$ signal line is sampled low at the beginning of T2. The TCU adds five wait states identified as TD0–TD4 into a normal bus cycle. The $\overrightarrow{\text{RD}}$ and $\overline{\rm WR}$ signals are also re-shaped so the setup and hold times for address and data will be increased.

This may be necessary when slower peripherals must be accessed.

Figure 1-10 shows the timing diagram of a peripheral cycle.



1.0 Functional Description (Continued) 1.7.3 Cycle Hold

If the $\overline{\text{CWAIT}}$ input is sampled low at the end of state T1, the TCU will go into cycle hold mode and stay in this mode for as long as CWAIT is kept low. During this mode the control signals $\overline{\text{RD}}$, $\overline{\text{WR}}$, $\overline{\text{TSO}}$ and $\overline{\text{DBE}}$ are kept inactive; RDY is

pulled low, thus causing wait states to be inserted into the bus cycle. The cycle hold feature can be used in applications involving dynamic RAMs. A timing diagram showing the cycle hold feature is shown in Figure 1-11.



FIGURE 1-11. Cycle Hold Timing Diagram

1.8 BUS CYCLE EXTENSION COMBINATIONS

Any combination of the TCU input signals used for extending a bus cycle can be activated at one time. The TCU will honor all of the requests according to a certain priority scheme. A cycle hold request is assigned top priority. It follows a peripheral cycle request, and then CWAIT and WAITn respectively.

If, for example, all the input signals CWAIT, PER and WAITn are asserted at the beginning of the cycle, the TCU will enter the cycle hold mode. As soon as CWAIT goes high, the input signal PER is sampled to determine whether a peripheral cycle is requested.

Next, the TCU samples $\overline{\text{CWAIT}}$ again and $\overline{\text{WAITn}}$ to check whether additional wait states have to be inserted into the bus cycle. This sampling point depends on whether $\overline{\text{PER}}$ was sampled high or low. If PER was sampled high, then the sampling point will be in the middle of the TCU state T2, (Figure 1-14), otherwise it will occur three clock cycles later (Figure 1-15). Figures 1-12 to 1-15 show the timing diagrams for different combinations of cycle extensions.









The TCU handles the $\overline{\text{WAITn}}$ Wait States by means of an internal counter that is reloaded with the binary value corresponding to the state of the $\overline{\text{WAITn}}$ inputs each time $\overline{\text{CWAIT}}$ is sampled low, and is decremented when $\overline{\text{CWAIT}}$ is high. This allows to either extend a bus cycle of a predefined number of clock cycles, or prematurely terminate it. To ter-

minate a bus cycle, for example, CWAIT must be asserted for at least one clock cycle, and the $\overline{\text{WAITn}}$ inputs must be forced to their inactive state.

At least one wait state is always inserted when using this procedure as a result of CWAIT being sampled low. *Figure 1-16* shows the timing diagram of a prematurely terminated bus cycle where eleven wait states were being inserted.



2.0 Device Specifications

2.1 PIN DESCRIPTIONS

The following is a description of all NS32C201 pins. The descriptions reference portions of the Functional Description, Section 1.

2.1.1 Supplies

Power (V_{CC}): +5V positive supply. Section 1.1. **Ground (GND):** Power supply return. Section 1.1.

2.1.2 Input Signals

Reset Input (RSTI): Active low. Schmitt triggered, asynchronous signal used to generate a system reset. Section 1.4.

Address Strobe (ADS): Active low. Identifies the first timing state (T1) of a bus cycle.

Data Direction Input (DDIN): Active low. Indicates the direction of the data transfer during a bus cycle. Implies a Read when low and a Write when high.

Note: In Rev. A of the NS32C201 this signal is CMOS compatible. In later revisions it is TTL compatible.

Read/Write Enable and Synchronization (\overline{RWEN} / **SYNC):** TRI-STATE® the \overline{RD} and the \overline{WR} outputs when high and enables them when low. Also used to synchronize the phase of the TCU clock signals, when two or more TCUs are used. Section 1.5.

Crystal or External Clock Source (XIN): Input from a crystal or an external clock source. Section 1.3.

Continuous Wait (CWAIT): Active low. Initiates a continuous wait if sampled low in the middle of T2 during a Fast cycle, or in the middle of TD2, during a peripheral cycle. If CWAIT is low at the end of T1, it initiates a Cycle Hold. Section 1.7.1.

Four-Bit Wait State Inputs (WAIT1, WAIT2, WAIT4 and WAIT8): Active low. These inputs, (collectively called WAITn), allow from zero to fifteen wait states to be specified. They are binary weighted. Section 1.7.1.

Peripheral Cycle (PER): Active low. If active, causes the TCU to insert five wait states into a normal bus cycle. It also causes the Read and Write signals to be re-shaped to meet the setup and hold timing requirement of slower MOS peripherals. Section 1.7.2.

2.1.3 Output Signals

Reset Output (RSTO): Active low. This signal becomes active when RSTI is low, initiating a system reset. RSTO goes high on the first rising edge of PHI1 after RSTI goes high. Section 1.4.

Read Strobe (RD): (TRI-STATE) Active low. Identifies a Read cycle. It is decoded from DDIN and TRI-STATE by RWEN/SYNC. Section 1.6.

Write Strobe (WR): (TRI-STATE) Active low. Identifies a Write cycle. It is decoded from DDIN and TRI-STATE by RWEN/SYNC. Section 1.6.

Note: $\overline{\text{RD}}$ and $\overline{\text{WR}}$ are mutually exclusive in any cycle. Hence they are never low at the same time.

Data Buffer Enable (DBE): Active low. This signal is used to control the data bus buffers. It is low when the data buffers are to be enabled. Section 1.6.

Timing State Output (TSO): Active low. The falling edge of \overline{TSO} signals the beginning of state T2 of a bus cycle. The rising edge of \overline{TSO} signals the beginning of state T4. Section 1.6.

Ready (RDY): Active high. This signal will go low and remain low as long as wait states are to be inserted in a bus cycle. It is normally connected to the RDY input of the CPU. Section 1.7.

Fast Clock (FCLK): This is a clock running at the same frequency as the crystal or the external source. Its frequency is twice that of the CPU clocks. Section 1.3.

CPU Clocks (PHI1 and PHI2): These outputs provide the Series 32000 CPU with two phase, non-overlapping clock signals. Their frequency is half that of the crystal or external source. Section 1.3.

System Clock (CTTL): This is a system version of the PHI1 clock. Hence, it operates at the CPU clock frequency. Section 1.3.

Crystal Output (XOUT): This line is used as the return path for the crystal (if used). It must be left open when an external clock source is used to drive XIN. Section 1.2.

2.0 Device Specifications (Continued)

2.2 ABSOLUTE MAXIMUM RATINGS (Note 1) If Military/Aerospace specified devices are required, please contact the National Semiconductor Sales Office/Distributors for availability and specifications.

Supply Voltage	/V
Input Voltages	$-0.5V$ to $V_{\mbox{CC}}$ $+$ $0.5V$
Output Voltages	$-0.5V$ to $V_{\mbox{CC}}$ $+$ $0.5V$
Storage Temperature	-65°C to +150°C
Lead Temperature (Soldering, 10 sec.) 300°C
Continous Power Dissipation	1W

Note: Absolute maximum ratings indicate limits beyond which permament damage may occur. Continuous operation at these limits is not intended; operation should be limited to those conditions specified under Electrical Characteristics.

2.3 ELECTRICAL CHARACTERISTICS $T_{A}=~-40^{\circ}C$ to $+85^{\circ}C,\,V_{CC}=~5V~\pm5\%,\,GND=~0V$

Symbol	Parameter	Conditions	Min	Тур	Max	Units
VIL	Input Low Voltage	All Inputs Except RSTI & XIN			0.8	V
VIH	Input High Voltage	All Inputs Except RSTI & XIN				V
V _{T+}	RSTI Rising Threshold Voltage	$V_{CC} = 5.0V$	2.5		3.5	V
V _{HYS}	RSTI Hysteresis Voltage	$V_{CC} = 5.0V$	0.8		1.9	V
V _{XL}	XIN Input Low Voltage				0.20 V _{CC}	V
V _{XH}	XIN Input High Voltage		0.80 V _{CC}			V
IIL	Input Low Current	$V_{IN} = 0V$			-10	μA
IIH	Input High Current	$V_{IN} = V_{CC}$			10	μA
V _{OL}	Output Low Voltage PHI1 & PHI2, I = 1 mA All Other Outputs Except XOUT, I = 2 mA				0.10 V _{CC}	v
V _{OH}	Output High Voltage	All Outputs Except $XOUT$, I = -1 mA 0.90 V _{CC}				v
١L	Leakage Current on RD/WR	$0.4V \le V_{IN} \le V_{CC}$	-20		+20	μA
Icc	Supply Current	f _{xin} = 20 MHz		100	120	mA

Note 1: All typical values are for V_{CC} = 5V and T_A = 25°C.

Connection Diagram



2.0 Device Specifications (Continued) 2.4 SWITCHING CHARACTERISTICS

2.4.1 Definitions

2.4.3 Timing Tables

All the timing specifications given in this section refer to 2.0V on the rising or falling edges of the clock phases PHI1 and PHI2; to 15% or 85% of V_{CC} on all the CMOS output signals, and to 0.8V or 2.0V on all the TTL input signals, unless specifically stated otherwise.

2.4.2 Output Loading

 Capacitive loading on output pins for the NS32C201.

 RDY, DBE, TSO
 .50 pF

 RD, WR
 .75 pF

 CTTL
 .50 ÷ 100 pF

 FCLK
 .100 pF

 PHI1, PHI2
 .170 pF

ABBREVIATIONS

L.E.—Leading Edge T.E.—Trailing Edge R.E.—Rising Edge F.E.—Falling Edge

Symbol	Figure	Description	Description Reference/Conditions	NS32C201-10		NS32C201-15		Units
Cymbol			Min	Max	Min	Max		
CLOCK-SIG	GNALS (XIN	I, FCLK, PHI1 & PHI2) TIMINO	G					
t _{Cp}	2.2	Clock Period	PHI1 R.E. to Next PHI1 R.E.	100		66		ns
t _{CLh}	2.2	Clock High Time	At 90% V _{CC} on PHI1 (Both Edges)	0.5 t _{Cp} — 15 ns	0.5 t _{Cp} 7 ns	0.5 t _{Cp} — 10 ns	0.5 t _{Cp} −3 ns	
t _{CLI}	2.2	Clock Low Time	At 15% V _{CC} on PHI1	0.5 t _{Cp} -5 ns	0.5 t _{Cp} + 10 ns	0.5 t _{Cp} 5 ns	0.5t _{CP} + 6 ns	
t _{CLw(1,2)}	2.2	Clock Pulse Width	At 2.0V on PHI1, PHI2 (Both Edges)	0.5 t _{CP} 10 ns	0.5 t _{CP} 4 ns	0.5 t _{CP} 6 ns	0.5 t _{CP} -4 ns	
t _{CLwas}		PHI1, PHI2 Asymmetry (t _{CLw} (1) – t _{CLw} (2))	At 2.0V on PHI1, PHI2	-5	5	-3	3	ns
t _{CLR}	2.2	Clock Rise Time	15% to 90% V _{CC} on PHI1 R.E.		8		6	ns
t _{CLF}	2.2	Clock Fall Time	90% to 15% V _{CC} on PHI1 F.E.		8		6	ns
t _{nOVL (1,2)}	2.2	Clock Non-Overlap Time	At 15% V _{CC} on PHI1, PHI2	-2	+2	-2	+2	ns
t _{nOVLas}		Non-Overlap Asymmetry (t _{nOVL} (1) – t _{nOVL} (2))	At 15% V _{CC} on PHI1, PHI2	-4	4	-3	3	ns
t _{Xh}	2.2	XIN High Time (External Input)	At 80% V _{CC} on XIN (Both Edges)	16		10		ns
t _{XI}	2.2	XIN Low Time (External Input)	At 15% V _{CC} on XIN (Both Edges)	16		10		ns
t _{XFr}	2.2	XIN to FCLK R.E. Delay	80% V _{CC} on XIN R.E. to FCLK R.E.	6	29	6	25	ns
t _{XFf}	2.2	XIN to FCLK F.E. Delay	15% V _{CC} on XIN F.E. to FCLK F.E.	6	29	6	25	ns
t _{XCr}	2.2	XIN to CTTL R.E. Delay	80% V _{CC} on XIN R.E. to CTTL R.E.	6	34	6	25	ns
t _{XPr}	2.2	XIN to PHI1 R.E. Delay	80% V _{CC} on XIN R.E. to PHI1 R.E.	6	32	6	25	ns
t _{FCr}	2.2	FCLK to CTTL R.E. Delay	FCLK R.E. to CTTL R.E.	0	6	0	6	ns
t _{FCf}	2.2	FCLK to CTTL F.E. Delay	FCLK R.E. to CTTL F.E.	-3	4	-3	4	ns
t _{FPr}	2.3	FCLK to PHI1 R.E. Delay	FCLK R.E. to PHI1 R.E.	-3	4	-3	4	ns
t _{FPf}	2.3	FCLK to PHI1 F.E. Delay	FCLK R.E. to PHI1 F.E.	-5	2	-5	2	ns
t _{Fw}	2.3	FCLK Pulse Width with Crystal	At 50% V _{CC} on FCLK (Both Edges)	0.25 t _{Cp} —5 ns	0.25 t _{Cp} + 5 ns	0.25 t _{Cp} - 5 ns	0.25 t _{Cp} + 5 ns	
t _{PCf}	2.3	PHI2 R.E.to CTTL F.E. Delay	PHI2 R.E. to CTTL F.E.	-3	4	-3	3	ns
t _{CTw}	2.3	CTTL Pulse Width	At 50% V _{CC} on CTTL (Both Edges)	0.5 t _{Cp} -7 ns	0.5 t _{Cp} + 1 ns	0.5 t _{Cp} - 5 ns	0.5 t _{Cp} + 1 ns	

Note 1: $t_{XCr},\,t_{FCr},\,t_{FCf},\,t_{PCf},\,t_{CTh}$ are measured with 100 pF load on CTTL.

Note 2: PHI1 and PHI2 are interchangeable for the following parameters: t_{Cp}, t_{CLh}, t_{CL}, t_{CLw}, t_{CLF}, t_{nOVL}, t_{XPr}, t_{FPr}, t_{FPf},

0	Eine aus	Description	Deferrer (Or a little	NS320	201-10	NS320	201-15	
Symbol	Figure	Description	Reference/Conditions	Min	Мах	Min	Max	
CTTL TIN	IING (CL =	50 pF)	11					
t _{PCr}	2.3	PHI1 to CTTL R.E. Delay	PHI1 R.E. to CTTL R.E.	-2	5	-2	3	ns
t _{CTR}	2.3	CTTL Rise Time	10% to 90% V _{CC} on CTTL R.E.		7		6	ns
t _{CTF}	2.3	CTTL Fall Time	90% to 10% V _{CC} on CTTL F.E.		7		6	ns
CTTL TIN	IING (CL $=$	100 pF)						
t _{PCr}	2.3	PHI1 to CTTL R.E. Delay	PHI1 R.E. to CTTL R.E.	-2	6	-2	4	ns
t _{CTR}	2.3	CTTL Rise Time	10% to 90% V _{CC} on CTTL R.E.		8		7	ns
tCTF	2.3	CTTL Fall Time	90% to 10% V _{CC} on CTTL F.E.		8		7	ns
CONTRO	L INPUTS (R	ST1, ADS, DDIN) TIMING			•			
t _{RSTs}	2.4	RSTI Setup Time	Before PHI1 R.E.	20		15		
t _{ADs}	2.4	ADS Setup Time	Before PHI1 R.E.	25		20		ns
t _{ADw}	2.4	ADS Pulse Width	ADS L.E. to ADS T.E.	25		20		ns
t _{DDs}	2.4	DDIN Setup Time	Before PHI1 R.E.	15		13		ns
CONTRO	L OUTPUTS	(RSTO, TSO, RD, WR, DBE & RWEN	SYNC) TIMING					
t _{RSTr}	2.4	RSTO R.E. Delay	After PHI1 R.E.		21		10	ns
t _{Tf}	2.5	TSO L.E. Delay	After PHI1 R.E.		12		8	ns
t _{Tr}	2.5	TSO T.E. Delay	After PHI1 R.E.	3	18	3	10	ns
t _{RWf(F)}	2.5	RD/WR L.E. Delay (Fast Cycle)	After PHI1 R.E.		30		21	ns
t _{RWf(S)}	2.6	RD/WR L.E. Delay (Peripheral Cycle)	After PHI1 R.E.		25		15	ns
t _{RWr}	2.5/6	RD/WR T.E. Delay	After PHI1 R.E.	3	20	3	15	ns
t _{DBf(W)}	2.5/6	DBE L.E. Delay (Write Cycle)	After PHI1 R.E.		25		15	ns
t _{DBf(R)}	2.5/6	DBE L.E. Delay (Read Cycle)	After PHI2 R.E.		20		11	ns
t _{DBr}	2.5/6	DBE T.E. Delay	After PHI2 R.E.		20		15	ns
t _{pLZ}	2.7	RD,WR Low Level to TRI-STATE	After RWEN/SYNC R.E.		25		20	ns
t _{pHZ}	2.7	RD, WR High Level to TRI-STATE	After RWEN/SYNC R.E.		20		15	ns
t _{pZL}	2.7	RD,WR TRI-STATE to Low Level	After RWEN/SYNC F.E.		25		18	ns
t _{pZH}	2.7	RD,WR TRI-STATE to High Level	After RWEN/SYNC F.E.		25		18	ns
WAIT ST	ATES & CYC	LE HOLD (CWAIT, WAITn, PER & R	DY) TIMING					
t _{CWs(H)}	2.8	CWAIT Setup Time (Cycle Hold)	Before PHI1 R.E.	30		20		ns
t _{CWh(H)}	2.8	CWAIT Hold Time (Cycle Hold)	After PHI1 R.E.	0		0		ns
t _{CWs(W)}	2.8/9	CWAIT Setup Time (Wait States)	Before PHI2 R.E.	10		6		ns
t _{CWh(W)}	2.9	CWAIT Hold Time (Wait States)	After PHI2 R.E.	20		10		ns
t _{Ws}	2.9	WAITn Setup Time	Before PHI2 R.E.	7		6		ns
t _{Wh}	2.9	WAITn Hold Time	After PHI2 R.E.	15		10		ns
t _{Ps}	2.10	PER Setup Time	Before PHI1 R.E.	7		5		ns
t _{Ph}	2.10	PER Hold Time	After PHI1 R.E.	30		20		ns
t _{Rd}	2.8/9/10	RDY Delay	After PHI2 R.E.		25		12	ns
SYNCHR	ONIZATION	(SYNC) TIMING	· · · · · ·					
t _{Sys}	2.11	SYNC Setup Time	Before XIN R.E.	6		6		ns
t _{Syh}	2.11	SYNC Hold Time	After XIN R.E.	5		5		ns
t _{CS}	2.11	CTTL/SYNC Inversion Delay	CTTL (master) to		10		7	ns













National does not assume any responsibility for use of any circuitry described, no circuit patent licenses are implied and National reserves the right at any time without notice to change said circuitry and specifications

This datasheet has been download from:

www.datasheetcatalog.com

Datasheets for electronics components.