## **Software Chip Erase**

The entire device can be erased at one time by using a 6-byte software code. The software chip erase code consists of 6-byte load commands to specific address locations with specific data patterns. Once the code has been entered, the device will set each byte to the high state (FFH). After the software chip

erase has been initiated, the device will internally time the erase operation so that no external clocks are required. The maximum time required to erase the whole chip is  $t_{\rm EC}$  (20 ms). The software data protection is still enabled even after the software chip erase is performed.


## **Chip Erase Cycle Characteristics**

Symbol	Parameter	
t <sub>EC</sub>	Chip Erase Cycle Time	20 ms Max

Note:

1. Please refer to individual data sheets for the minimum and maximum values of the  $t_{AS}$ ,  $t_{AH}$ ,  $t_{DS}$ ,  $t_{DH}$ ,  $t_{WP}$   $t_{BLC}$ , and  $t_{WPH}$  parameters.

## **Chip Erase Software Algorithm**<sup>(1)(3)</sup>



Notes:

- 1. Data Format: (Hex); Address Format: (Hex).
- 2. After loading the 6-byte code, no byte loads are allowed until the completion of the erase cycle. The erase cycle will time itself to completion in 20 ms (max).
- 3. The flow diagram shown is for a x8 part. For a x16 part, the data should be 16 bits long (e.g., the data to be loaded should be AAAA for step 1 in the algorithm).



# Parallel EEPROMs


# Application Note

Rev. 0544B-10/98





# **Chip Erase Cycle Waveforms**



Note: 1.  $\overline{OE}$  must be high only when  $\overline{WE}$  and  $\overline{CE}$  are both low.





## **Atmel Headquarters**

#### Corporate Headquarters

2325 Orchard Parkway San Jose, CA 95131 TEL (408) 441-0311 FAX (408) 487-2600

#### **Europe**

Atmel U.K., Ltd. Coliseum Business Centre Riverside Way Camberley, Surrey GU15 3YL **England** TEL (44) 1276-686677 FAX (44) 1276-686697

### Asia

Atmel Asia, Ltd. Room 1219 Chinachem Golden Plaza 77 Mody Road Tsimshatsui East Kowloon, Hong Kong TEL (852) 27219778 FAX (852) 27221369

#### Japan

Atmel Japan K.K. Tonetsu Shinkawa Bldg., 9F 1-24-8 Shinkawa Chuo-ku, Tokyo 104-0033 Japan TEL (81) 3-3523-3551 FAX (81) 3-3523-7581

### **Atmel Operations**

#### Atmel Colorado Springs

1150 E. Chevenne Mtn. Blvd. Colorado Springs, CO 80906 TEL (719) 576-3300 FAX (719) 540-1759

#### Atmel Rousset

Zone Industrielle 13106 Rousset Cedex, France TEL (33) 4 42 53 60 00 FAX (33) 4 42 53 60 01

> Fax-on-Demand North America: 1-(800) 292-8635 International:

1-(408) 441-0732

e-mail literature@atmel.com

Web Site http://www.atmel.com

BBS1-(408) 436-4309

#### © Atmel Corporation 1998.

Atmel Corporation makes no warranty for the use of its products, other than those expressly contained in the Company's standard warranty which is detailed in Atmel's Terms and Conditions located on the Company's website. The Company assumes no responsibility for any errors which may appear in this document, reserves the right to change devices or specifications detailed herein at any time without notice, and does not make any commitment to update the information contained herein. No licenses to patents or other intellectual property of Atmel are granted by the Company in connection with the sale of Atmel products, expressly or by implication. Atmel's products are not authorized for use as critical components in life support devices or systems.

Marks bearing ® and/or ™ are registered trademarks and trademarks of Atmel Corporation.

Terms and product names in this document may be trademarks of others.

